

Cladding Cleaning Guide

Initial Cleaning Preparation

After the installation of all sheets and joints, ensure an adequate period for the adhesives/sealants to complete curing before cleaning. Start by peeling off the protective film from sheets and profiles, then clean all surfaces using an anti-static solution or anti-static cleaning wipes. This step is crucial as the sheets may accumulate static, causing atmospheric dust to adhere to their surfaces.

GLOSS AND SATIN WALL CLADDING

Regular Cleaning

For cleaning the sheets, it is recommended to use a soft cloth with a mild soap/detergent, ensuring that the water or cleaning solution temperature does not exceed 60°C. To minimize static build-up, consider using an anti-static solution or anti-static cleaning wipes. For stubborn stains, an alkaline cleaner paired with a soft cloth is suggested. Pressure cleaning with hot water is permissible, but maintain a minimum distance of 2 feet (600mm) between the pressure nozzle and the sheet's surface to prevent damage. Be cautious, as some cleaning products containing abrasives or solvents may negatively impact the sheets. Establishing a regular cleaning routine, tailored to the area's usage and traffic, is advisable. For hygienic environments, a thorough cleaning of the sheets is recommended at least once a week.

DECORATIVE WALL CLADDING

Regular Cleaning

To preserve the product's condition, regular cleaning is permissible using appropriate household cleaning agents. The abrasion-resistant coating enhances protection against chemical attack.

- Use lukewarm water to rinse and soften dirt
- A solution of lukewarm water and ordinary household cleaner or mild soap for cleaning
- A sponge or soft cloth should then be used to gently remove dirt and grime
- Ethyl alcohol or white kerosene may be used sparingly to remove paint and other such substances

However, do not:

- Scrub the sheet with brushes or sharp implements
- Use squeegees
- Use harsh solvents for prolonged periods of time, other than those listed, or any abrasive
- cleaners Avoid cleaners of a highly alkaline composition

Always finish by rinsing with clean water.

The information provided in this guide was believed to be accurate at the time of preparation or prepared from sources believed to be reliable, but it is the responsibility of the user to investigate and understand other pertinent sources of information, to comply with all laws and procedures applicable to the use of the product and to determine the suitability of the product for its intended use.